CATALYST™ CHAIR CONTROL / SEAT CUSHION ASSEMBLY
Installation Instructions

NOTE: Note difference in length of screws used to attach cushion to chair control.

1. The two, type S.W., panhead screws which measure 1¼" must be inserted into front outside holes of chair control (Fig. 1).
2. Remaining four, type S.W., panhead screws measuring 1" in length are used in remaining four holes (Fig. 1).

