
INTUITY ®

Benching Assembly


Installation Instructions

Tools Required



SINGLE DESK


Desk with Straight Legs





Desk with Angled Legs




Shared Legs











Refer to instruction: 7029-9868




CUSTOMER SERVICE PHONE: 1-800-426-8562

DOUBLE BENCHING


Benching with Straight Leg




Benching with Angled Leg




Benching with Shared Leg



Benching with Column






(F)
#10-12 x 1" Pan Head Screw


(J2)
#8-32 x 3/8" Thread Forming Pan Head Screw

(B1)
M6 X 8mm Set Screw

(B3)
M6 x 16mm Pan Head Torx Screw





Refer to instruction: 7029-9868




SINGLE DESK

1a **Install frame assembly (B) to end support leg (D)**








(B1)
M6 X 8mm Set Screw


(B3)
M6 x 16mm Pan Head Torx Screw


ONLY USED WITH HATCHES




DOUBLE BENCHING

1b **Install frame assembly (B) to end support leg (D)**





ONLY USED WITHOUT HATCHES




(B1)
M6 X 8mm Set Screw

(J2)
#8-32 x 3/8" Thread Forming Pan Head Screw


SINGLE DESK SHARED

1a **Relocate rail end (K1) from starter to add-on**




DOUBLE BENCHING SHARED

1b **Relocate rail end (K2) from starter to add-on**




SINGLE DESK SHARED

2a Install add-on desk (N)



DOUBLE DESK SHARED

2b Install add-on desk (N)




SINGLE DESK SHARED

3a **Install frame (B) to shared support leg (D2)**

(M)
M6 X 14mm Low Profile Flat Head


(B3)
M6 x 16mm Pan Head Torx Screw




DOUBLE BENCHING SHARED

3b **Install frame (B) to shared support leg (D2)**

(B3)
M6 x 16mm Pan Head Torx Screw




3c Install frame (B) to shared column (R1)





(B3)

M6 x 16mm Pan Head Torx Screw

4 Install column covers (R2)








DOUBLE UTILITY TRAY

5 **Install utility tray (J)**

(J3)
#10 x 3/8" Screw





SINGLE UTILITY TRAY


6 **Install utility tray (H)**

(J4)
#10-24 x 3/4" Screw


(J3)
#10 x 3/8" Screw








CUSTOMER SERVICE PHONE: 1-800-426-8562

(H1)

#8-32 x 3/4" Pan Head Screw


7a Install utility tray (H)





ONLY USED WITHOUT HATCHES

ONLY USED WITH HATCHES

7b


(H1)

#8-32 x 3/4" Pan Head Screw





WORKSURFACE WITH HATCHES

8a **Install worksurface (A)**




(F)

#10-12 x 1" Pan Head Screw

WORKSURFACE WITHOUT HATCHES

8b **Install worksurface (A)**




INTUITY ®

120˚ Benching Assembly


Installation Instructions


SINGLE DESK


Desk with Straight Legs





Desk with Angled Legs






















Refer to instruction: 7029-9868





CUSTOMER SERVICE PHONE: 1-800-426-8562


Benching with Straight Leg




Benching with Angled Leg













Refer to instruction: 7029-9868











1 Install frame assembly (B) to end support leg (D). Install center post leg (L).

(B1)
M6 X 8mm Set Screw

(B3)
M6 x 16mm Pan Head Torx Screw







2 Install utility tray (K).


(H1) #8-32 x 3/4" Pan Head Screw

(J3) #10 x 3/8" Screw




ONLY USED WITHOUT HATCHES






3 Install cover (M).


(H1)



#8-32 x 3/4" Pan Head Screw


Note: Some items removed from illustration for clarity.







6 Attach worksurface (A).

(F)



#10-12 x 1" Pan Head Screw







1 **Install frame assembly (B) to end support leg (D) on all three assemblies. Install leg (L) onto all three assemblies.**

(B1)
M6 X 8mm Set Screw


(B3)
M6 x 16mm Pan Head Torx Screw

(J2)
#8-32 x 3/8" Thread Forming Pan Head Screw






3 Install adjoining frames (B).




(B3)


M6 x 16mm Pan Head Torx Screw


5 Install top cap (O). Install optional covers (P) using double stick tape (Q).







Note: Some items removed from illustrations for clarity.










7 Install worksurfaces (A).


(F)




#10-12 x 1" Pan Head Screw

SINGLE DESK SCREEN


9 Snap screen (S) into channel



10 Insert wedge (S1) into channel (B)





11 Slide wedge (S1) to lock screen




CUSTOMER SERVICE PHONE: 1-800-426-8562

1a Install support leg






(D4)




#10-12 x 1.25" FH

2 Install return

(F)




#10-12 x 1" Pan Head Screw




BENCH END

1


(D4)
#10-12 x 1.25" FH
D4
A3

2



(B3)
M6 x 16mm Pan Head Torx Screw

2
1
1
B3
T1
T2

BENCH END


3

(F)



#10-12 x 1" Pan Head Screw

(B3)



M6 x 16mm Pan Head Torx Screw

