

ENHANCED PREMISE®


Enhanced Premise Wing Wall Panel


Installation Instructions


Tools Required
















1 Assemble mounting brackets (B)


NOTE: Do not assemble top mounting bracket at this time.


NOTE: If worksurface will be installed, bracket **(E)** should be installed at this time.




RIGHT HAND











NOTE: Item (C) must always go through bracket (B).




LEFT HAND




2 Attach rubber spacer (D) to top bracket

NOTE: Only use spacer if **no** components are being installed against the wing wall.




3 Insert top mounting bracket (B)


NOTE: Location of mounting bracket will vary depending on height of wing panel. Full height shown.




CUSTOMER SERVICE PHONE: 1-800-426-8562


4 Install wing wall (A)










5 Installing a work surface





NOTE: Install item (C) as shown.







Installing Corner Work Surfaces

NOTE: When installing corner work surfaces the wing wall must be 3 feet or larger.


6 **Install one support bracket (E)**







7 **Use bracket as template to locate and drill 3/8" hole**


8 **Install corner work surface**





Lower Wing Wall Options















9 Assemble mounting bracket (B)


NOTE: Do not assemble top mounting bracket at this time.

















10 Insert top mounting bracket (B)




11 Install wing wall (A)




12 Installing a work surface








CUSTOMER SERVICE PHONE: 1-800-426-8562

Upper Wing Wall Options









13 **Assemble mounting brackets (B)**

NOTE: Do not assemble top mounting bracket at this time.

14 **Install upper wing wall (A) (Repeat steps 10-11)**

15 **Install support bracket(s) (N)**

