
# IMMERSE®

## Stack Table


Installation Instructions

**Tools Required**




**PARTS**


(E1)



3/8 x 1-1/2" Socket Head Cap Screw

**FOR WOOD/ LAMINATE TOPS**


(D)



#12 x 1" Pan Head Screw


**FOR SOLID SURFACE TOPS**

(D1)




#12 x 1/2" Screw

(L)



#10 x 1/2" Flat Head Screw

(J2)



Flat Washer


(C)



#12-24 Flange Hex Nut

**FOR SOLID SURFACE SILL**


(C2)




#12-24 x 1" Flat Head Screw

**FOR LAMINATE SILL**


(C3)



#12-24 x 1.25" Pan PH, MS, S





(J)



3/8 x 4" Socket Head Cap Screw


**CUSTOMER SERVICE PHONE: 1-800-426-8562**

## PARTS






CUSTOMER SERVICE PHONE: 1-800-426-8562

**1**


(L)
#10 x 1/2" Flat Head Screw
L
M
B
M

**2**



(L)
#10 x 1/2" Flat Head Screw
M2
L
B2
M2
B2




CUSTOMER SERVICE PHONE: 1-800-426-8562


**5**

(J)




3/8 x 4" Socket Head Cap Screw

(J2)




Flat Washer

(E1)




3/8 x 1-1/2" Socket Head Cap Screw

(K6)




#8-15 x 5/8" Flat Head Screw

**FOR SOLID SURFACE SILL**





OR

**FOR LAMINATE SILL**





**1**

**FOR SOLID SURFACE SILL**





OR


**FOR LAMINATE SILL**





**1**

**4**





**5**





**6**




**Hand tighten all bolts using extension for extra torque/leverage.**

**3**





**2**

**FOR SOLID SURFACE SILL**





**FOR LAMINATE SILL**





**CUSTOMER SERVICE PHONE: 1-800-426-8562**


# 6a





**FOR USE WITH SOLID SURFACE SILL**





**FOR USE WITH LAMINATE SILL**



# 6b


(C)



#12-24 Flange Hex Nut

**FOR USE WITH SOLID SURFACE SILL**


(C2)




#12-24 x 1" Flat Head Screw

**FOR USE WITH LAMINATE SILL**

(C3)




#12-24 x 1.25" Pan PH, MS, S





# 7a

**FOR WOOD/LAMINATE TOPS**




**FOR SOLID SURFACE TOPS**




# 7b

**FOR WOOD/LAMINATE TOPS**


(D)



#12 x 1" Pan Head Screw


**FOR SOLID SURFACE TOPS**

(D1)




#12 x 1/2" Screw

(K6)




#8-15 x 5/8" Flat Head Screw

**Solid Surface Tops** | **Wood Tops** | **Laminate Tops**





**1**



## MOVING TABLE: WHAT NOT TO DO!


**⚠ IMPORTANT**

DO NOT LIFT THE TABLE BY THE EDGES!



**⚠ IMPORTANT**

DO NOT DRAG THE TABLE!




## MOVING TABLE: WHAT TO DO!

**1**

**⚠ IMPORTANT**

ALWAYS LIFT TABLE EVENLY AND DIRECTLY UNDER THE FRAME WHEN MOVING!




**2**




CUSTOMER SERVICE PHONE: 1-800-426-8562