
HAWORTH


Upside Bench

Assembly Instructions

Base Feed & Tray



Tools Required




WARNING: Do not electrically interconnect modular power distribution systems powered from two different power feed units. This poses a SHOCK HAZARD to service personnel and will cause RISK OF FIRE due to excessive circulating currents.

WARNING: Power to all branch circuits MUST REMAIN DISCONNECTED during installation or removal of electrical components and raceway covers to avoid SHOCK HAZARDS.

NOTE: Connections of this modular power distribution component **MUST** be done by a licensed electrician, who must control the size and loading of each branch circuit. The person or group installing Haworth products is responsible for complying with all applicable building and electrical code requirements.


Power Trough

NOTE: For power trough instructions refer to frame instructions
61000267
61000268
61000269




OR

Transition Tray




NOTE: Power tray and transition trays are ordered separately.


Base Feed




0 1/4 1/2 1/4 1


Scale 1 : 1









(C) Back Cover - Qty. 1




(H) Cover - Qty. 1




(J) Base Tray - Qty. 1



(Q) Brackets - Qty. 2




(S200) M6 X 10mm Button Head - Qty. 4



NOTE: Screws are supplied with Bench Frame.

(S142) #10-32 X 1/2" Screw - Qty. 4




(S349) #10-24 X 3/8" Screw - Qty. 4





1 Remove knock out

NOTE: For cable trough instructions refer to frame instructions
61000267 - Single
61000268 - Back-to-Back
61000269 - 120°
61000291 - Power Options





1 Assemble brackets (Q)






2 Assemble base (C)






3 Install transition tray (G1)




4 Install floor bracket (J)


WARNING! Appropriate screws/bolts (DD) must be used to attach bracket to floor. Due to various floor constructions, fasteners are not provided.




OPTIONAL ROUTING ABOVE FLOOR




5 Route cables and install cover



6 Route power and install cover (G2)





NOTE: For cable trough instructions refer to frame instructions
61000267 - Single
61000268 - Back-to-Back
61000269 - 120°
61000291 - Power Options